

Installation Guide

TensarCorp.com/AmeriGrid | 888-996-3580

with Tensar. TriAx[®] technology

Hardscaping Geogrid

Product Dimensions: 6 ft wide x 60 ft long

Soil Stabilization Geogrid for Hardscape Projects



STEP 1 Prepare Site





STEP 3 Overlap Edges



Pavers that stay in place & no call backs!

Install Checklist:

- □ Prepare site in accordance with project specifications
- Install geogrid before placing base material
- □ Gloves should be worn when handling and cutting
- □ Lay geogrid flat and free from folds
- □ Cut and overlap geogrid to accommodate curves using sharp shears or utility knife

Dig less & use less base material





Please refer to paver manufacturer for installation guidelines and construction recommendations. Geogrid use is at installer/owner's own risk.



THE COMPANY YOU CAN BUILD ON**